

# HTC

## Professional Floor Systems

### Product sheet

## Wood grinding tools

EZ SL Wood is the new diamond tool series for wood grinding from HTC.

The diamond tools EZ SL 30 and 50 are used to remove old lacquer and oil, and for levelling of uneven floors. The tools should always be used with flexible tool holders. When old finish has been removed from the floor, switch to sandpaper and continue grinding with finer grit sizes. Download the [EZwood™ grinding guide](#) for more information and our latest recommendations for wood grinding.



**EZ SL 30 Wood**  
(Item Number: 212186)

A coarse tool. A tool for levelling of uneven floors, e.g. duckboards, and removal of thick lacquer.



**EZ SL 50 Wood**  
(Item Number: 212187)

Recommended starting tool for most floors when removing lacquer and oil.



**EZ SL 70 Wood**  
(Item Number: 212343)

A finer step to be used before switching to abrasive paper and applying lacquer.



**Flexible Tool Holder EZ 180 3**  
(Item Number: 112794)

Flexible EZchange tool holder for HTC 420.



**Foamflex for wood**  
(Item Number: 211045)

Flexible pad for sandpaper. Always used when fine grinding and with coarse grinding if the surface is very uneven.

# HTC

## Professional Floor Systems

### Product sheet



**Abrasive Paper, 40**  
(Item Number: 11955)

Also available:

60 (11956), 80 (11957), 100 (11958), 120 (11959) (180mm)  
40 (11961), 60 (11960), 80 (11962), 100 (11963), 120 (11964) (230mm)

50 pcs in each package/grit size.



**Holder for pads**  
(Item Number: 210670)

Velcro holder for EZwood oil pads.



**Oiling pad HTC 420**  
(Item Number: 212010)

For oiling of wood floors.

